


Assembly Hardware Included



Tools Needed

- Hammer
- Utility Knife
- 3/4" Socket & Ratchet
- Torque Wrench
- 3/4" Wrench
- 3/8" Masonry Bit
- Hammer Drill

	4x4	4x6	4x8	6x4	6x6	6x8	8x4	8x6	8x8	QUANTITIES
1 1/2" Bolt	84	108	132	106	132	158	132	158	184	
3/8" Anchor	16	20	24	20	24	28	24	28	32	
1/2" Washer	156	196	240	192	240	288	240	288	336	
1/2" Nut	68	88	108	86	108	130	108	130	152	
1/2" Cage Nut	16	20	24	20	24	28	24	28	32	

- 1 - Start with any **B** corner by placing it to a corner edge of the space.
- 2 - Attach adjacent **A** panel to **B** corner using the 1 1/2" bolts with a washer on both the bolt and nut sides. Do not tighten, yet.
- 3 - Proceed with remaining panels until finished as shown in diagram. Add or subtract 2' A panels to create size of building purchased. If you have A/V (audio/video) panels, they can be substituted in any of the A panel locations.
- 4 - Install the roof **J** panels. The roof's square holes will have cage nuts on the outside. Use 1 1/2" bolts and washers from the inside. Do not tighten.
- 5 - Straighten and square walls. Using 3/4" socket and wrench, tighten and torque bolts as you square up. Tighten and torque roof.
- 6 - Using your utility knife, cut an X in the carpet at the anchor hole locations.
- 7 - Using a 3/8" masonry bit, drill 4" deep holes at the anchor hole locations. Tap in wedge anchors in holes. Put washer and nut on anchor and tighten to manufacturer-recommended 25 lbs. torque.

